



Epson SureColor SC-P600

Hahnemühle Photo Matt Fibre / Duo  
Hahnemühle Photo Canvas

# Hahnemühle Photo

Digital Photo Media

## User Instruction

### Profiles for Hahnemühle Photo

We provide ICC profiles for the families of printers Epson Stylus Pro, Canon iPF, Canon Pixma Pro and Hewlett Packard Designjet. If you use a printer that does not derive from one of these families, please choose the settings for the best possible quality from the printer's manual or contact your printer's manufacturer.

### Settings

Printer drivers vary from printer to printer and from Macintosh to PC. The general settings, however, are the same. Make sure that you have chosen the right profile for your printer, paper and ink combination. The profile names indicate the fitting combination.

#### Print using Preview

- 1) Print: Document
- 2) Use of Colour: Printer profile fitting to your combination of paper and ink
- 3 & 4) Rendering Priority and Black-Point Compensation: This decision depends on the image you want to print. You may well have to try out the settings. For this reason, no recommendation can be made.

#### Printer Driver

- 5) Medium: Velvet Fine Art Paper
- 6) Quality: Superfine 1440 dpi
- 7) User-Defined Modus: Off  
(no colour correction)